



IR Control Codes

Settings:

IR remote frequency	38 KHz
IR remote range	≤ 15m

Codes

Function	Address	ID	Command	Verification
up	59	F8	AA	address ^ ID ^ command
down	59	F8	5A	address ^ ID ^ command
left	59	F8	BA	address ^ ID ^ command
right	59	F8	5B	address ^ ID ^ command
tilt down	59	F8	CA	address ^ ID ^ command
tilt up	59	F8	5C	address ^ ID ^ command
on	59	F8	DA	address ^ ID ^ command
off	59	F8	5D	address ^ ID ^ command
learning code	59	F8	EA	address ^ ID ^ command
delete code	59	F8	5E	address ^ ID ^ command